

Αρχικές ρυθμίσεις λειτουργίας για τον DAR-5001B

1. Format της κάρτας SD σε διαμόρφωση FAT32 και τοποθέτησή στον DAR-5001B
2. Για την ρύθμιση ενεργοποίησης του μηνύματος πατάμε «μενού» (Σελ. 8 manual)
3. Με το βελάκι κατεβαίνουμε στην 5^η επιλογή και πατάμε enter (Play symbol)
4. Επιλέγουμε το Voltage.
5. Την 8^η και 9^η επιλογή τις αλλάζουμε σε «ON»
6. Την 10^η επιλογή επιλέγουμε τον χρόνο απάντησης του τηλεφωνητή (0 = δεν απαντάει)
7. Για να βάλουμε το προσωπικό ηχογραφημένο μας μήνυμα έχοντας ηχογραφήσει το μήνυμα (Pc, laptop, κινητό), μετατρέπουμε το αρχείο σε WAV 8Bit, 8000Hz, mono, PCM A-LAW στο παρακάτω link audio.online-convert.com (Δείτε την εικόνα)
8. Έπειτα βγάζουμε την κάρτα SD από το μηχάνημα και βάζουμε το ηχογραφημένο μήνυμα στην κάρτα με ονομασία « LeaveMessage »
9. Τοποθετούμε ξανά την κάρτα SD μέσα στον τηλεφωνητή, ο τηλεφωνητής έχει πάρει το μήνυμα και είναι έτοιμος να λειτουργήσει.

The image shows the web interface of audio.online-convert.com. At the top, there is a green box with the text "Drop Files here" and a "Choose Files" button. Below this, there are links for "Enter URL", "Dropbox", and "Google Drive". A "Start conversion" button is located below the green box. To the right of the "Start conversion" button, there is a link "Add example file". Below the "Start conversion" button, there is a section titled "Optional settings" which contains several dropdown menus and checkboxes:

- Change bit resolution: 8 Bit
- Change sampling rate: 8000 Hz
- Change audio channels: mono
- Trim audio: 00:00:00 to 00:00:00
- Normalize audio: ☐
- Show advanced options >
- PCM format: PCM A-law

It's "Series Connection" for DAR-5001A, both the two RJ11 ports should be conncted: Left for PSTN, and Right for Phone.



PSTN(left port)

Phone(right port)



1.5 Settings List

All settings must be operated on the home screen

Display	Function Description	Operation Method	Default
DATE	Date/time setting	Setup+Confirm	
VOLUME	Volume setting	Setup+1 times turn Down+Confirm	2
LCD LIGHT	LCD Contrast setting	Setup+2 times turn Down+Confirm	4
OFFHOOK VOLT	Voltage threshold setting	Setup+3 times turn Down+Confirm	10
REC TRIGGER	Start recording condition setting	Setup+4 times turn Down+Confirm	Voltage Trigger
MIN TIME	Minimum recording time setting	Setup+5 times turn Down+Confirm	1
MAX TIME	Maximum recording time setting	Setup+6 times turn Down+Confirm	120
VOICE	Voice announcement setting (not for C type)	Setup+7 times turn Down+Confirm	OFF
VOICE SPEAKER	Voice announcement to speaker	Setup+8 times turn Down+Confirm	OFF
MSG RING	Message ringing times setting	Setup+9 times turn Down+Confirm	0
MAX MSG TIME	Maximum message time setting	Setup+ 10 times turn Down + Confirm	15
VOICE SENS	Voice control sensitivity setting	Setup + 11 times turn Down + Confirm	5
FSK COR	FSK Correction time setting	Setup + 12 times turn Down + Confirm	OFF