

## Manual for P2P IP CAMERA Android APP





**Note :** Make sure that the phone is able to connect to the Internet before use the Android APP..

### • Download ways:





- Find the "CoolcamOP 6.0.apk" file in the CD. Install it at Android mobile phones. Please be patient until the Android APP is installed and displayed on the screen.
- Google users can shop, pea pods, 91 Assistant downloads, search the keyword "COOLCAMOP", find the P2PCAMOP software to install.



### 1. Initial interface



## 2. Add cameras



How to add cameras,pls check as below.







### Three ways to add cameras.


**One:** Click Search LAN, user can search and add cameras in one LAN, if the cameras and phones are not in one LAN, then cameras won't be searched.

**Two:** Click "Scan ID"  Scan the QR Code on the housing of IP camera.  It will find and add the ID automatically, then click to finish.




**Three:** Input the UID on the "Device ID" of the Android APP. The default username is: admin.No password.Note:the "Device ID" is on the bottom of the ip cameras.


- Graphic settings



Four graphic settings, click on the list to the right of the camera



### 3. Viewing interface




Click Back to exit monitoring interface

Click on the menu operation interface

- The camera interface:



● Camera full screen mode::





- |                     |                                 |                         |
|---------------------|---------------------------------|-------------------------|
| 1. Exit video views | 2. About image flip             | 3. Image upside down    |
| 4. Police closed    | 5. Report to the police to open | 6. On / off full screen |

- 7. On / off voice monitoring
- 8. Photo
- 9. Videos
- 10. Watch mode
- 11. Resolution switching
- 12. preset bit set
- 13. Power frequency setting
- 14. infrared light switch
- 15. Saturation
- 16. Contrast
- 17. Video parameters reset


**4. The interface button function Description**

**Edit camera:**



**Alarm events, camera pictures and videos:**






### 5.Remote video view



In video view inside "cell phone", "remote" video viewing, click on the remote to view the video

Supporting players such as: storm video




### Camera settings

The circular arrows corresponding to the right of the selected equipment  
Click equipment , to enter the camera settings interface , as shown below:



5.1 . **WiFi Setting** : click WIFI settings enter WIFI setting interface , the search near WIFI hotspot , choose a wireless router to enter the password , click OK , reboot your machine connected to WIFI , as shown below



5.2 . **User Settings:** Can set user name and password of the administrator and operator

back      **User Setting**      done

Administrator

User:

Pwd:

Show Password

---

Operator

User:

Pwd:

Show Password

**5.3 . Alarm settings:** You can set the alarm parameters

back      **Alarm Setting**      done

Motion Detect Armed

Motion Detect Sensibility

Alarm Input Armed

Alarm trigger event

Alarm preset linkage      No

IO Linkage on Alarm

Alarmed Mail Notification

Alarmed Record

Upload Image on Alarm

**5.4 Mail Settings:** You must fill in the correct sender and receiver mailbox and mail server parameters

back Mail Setting done

Sender Demo@sina.com

SMTP Server smtp.sina.com

SMTP Port 0

Need Check

SSL NONE

SMTP User Demo

SMTP Password \*\*\*\*\*

Receiver1 test@163.com

Receiver2 test@yahoo.cn

Receiver3 test@gmail.com

Receiver4

